


Servo Press JP Series 5 Stand-Alone Type (Flexible Model)


How to Read the Model No. / Serial No.

Plate is affixed to press unit.

Identification Plate Positions



How to Check the Identification Plate



① Model Number

② Serial Number

Example: 20F10N0001