





Desktop Robot JR2000N Series


How to Read the Model No. / Serial No.

Plate is affixed to robot.

Identification Plate Positions



How to Check the Identification Plate



① Model Number

② Serial Number

Example: 16JRN20001

(CE Specifications)

