


Desktop Robot JR3000 Series

How to Read the Model No. / Serial No.


Plate is affixed to robot.

Identification Plate Positions


JR3203N-AC



JR3303N-AJ



How to Check the Identification Plate



① Model Number

② Serial Number

Example: 16JR32E0001